



Power Bank

Model:TSIMNT36021962

PRODUCT GUIDE

Read all the instructions before using the product

Date_Revision
April 8, 2025_V1.0

What's in the box?

Check to make sure you have everything below.

- onn 5000mAh portable battery
- USB-C to USB charging cable 1ft(30.4cm)
- User manual

Get to Know Your Power Bank

Specification

- Rated Capacity: 5000mAh/3.6V/18Wh
- Actual Capacity: 2700mAh/5V
- Input: USB-C 5V=2.4A
- Output: USB-C 5V=2.4A, USB-A 5V=2.4A, total 5V=2.4A, 12W Max
- Dimension: 96.0*63.0*13.5mm

(Rated capacity is battery cell capacity, actual capacity is USB-C 5V output capacity. Performance will vary based on settings and environmental conditions, and will decrease over time and with use.)

This product can charge your device with battery capacity less than 3500mAh one time (calculated according to the conversion efficiency of the product 80% and the reception efficiency of your device 90%)


We would love to hear from you. Scan with your Walmart app and let us know what you think.



Date_Revision
April 8, 2025_V1.0

Charging your Product

01



Fully charge the product before using it for the first time

- Plug one end of the included USB-C cable into the USB-C female port of the product
- Plug the other end into a standard USB-A port on your computer, car charger, or wall charger (not included)
- The product will start to charge automatically and the LED starts blinking. All 4 LEDs will become solid when the product is fully charged.
- The fully charge time of the product ≤ 4 hours (input $\geq 12W$)

Note:

Charging the product via a computer or a charger with an output below 5V/2.4A may take longer time to achieve a full charge.

Date_Revision
April 8, 2025_V1.0

Charging your Devices

02

- Plug one end of the included USB-C cable into the USB-A port of the product
- Plug the other end into your device. The product automatically begins charging your device.



Note:

If your device requires a different connector than the one provided, use the cable that came with your device.

Battery Capacity LED Indicator & Power Button

- ●●●● = 75% - 100%
- ●●●○ = 50% - 75%
- ✱○○○ Blinking LED = $< 5\%$ power
- ○○○○ If none of the LEDs light, your battery needs to be recharged
- ●●○○ = 25% - 50%
- ○○○○ = 1% - 25%
- Short press the button once to display the current power. LEDs will turn off after $30 \pm 8S$.

Small Current

- This product supports to charge devices which require very small current, such as bluetooth earphone(The LEDs may be off when charging those devices).

Date_Revision
April 8, 2025_V1.0

FCC Information

This device complies with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance with the FCC Rules could void the authority of the user to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced technician for help.

Date_Revision
April 8, 2025_V1.0

Safety and Compliance

- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not expose the product to rain or snow.
- Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or injury to persons.
- Do not use the the product in excess of its output rating.
- Overload outputs above rating may result in a risk of fire or injury to persons.
- Do not use the product that is damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the product. Take it to a qualified service person when service or repair is required.
- Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose the product to fire or excessive temperature.
- Exposure to fire or temperature above 100°C may cause explosion.
- Switch off the product when not in use.
- If the product will not be used for an extended period of time, please take the following steps once every three months to ensure proper function:
 - Charge the product
 - Discharge the product by using it to supply power to a mobile device.
 - Recharge the product for 4 hours(input≥12W)

Date_Revision
April 8, 2025_V1.0

- Store the product in a cool, dry place to avoid short-circuiting and damaging the product. Do not store or transport the product with metal objects.
- Clean only with dry cloth, avoid cleaning the product with rough or chemical objects.
- The device is not a toy. Keep it out of the reach of children and pets.
- Protect the product from extreme temperatures, direct sunlight, strong jolts, flammable gases, vapors and solvents
- Protect the product against high humidity and wet conditions.
- Prevent the product from undergoing any mechanical stress.
- If it is no longer possible to operate the product safely, stop using it and prevent further or accidental use.
- Safe operation can no longer be guaranteed if the product:
 - is visibly damaged,
 - is no longer working properly,
 - has been stored for extended periods in poor conditions,
 - has been subjected to any serious transport-related stress.
- Please handle the product carefully. Jolts and impacts can damage the product.
- Also observe the safety and operating instructions of any other devices connected to the product.

Date_Revision
April 8, 2025_V1.0

- Never use the product immediately after it has been brought from a cold room into a warm one.
- Condensation could destroy the product.
- Allow the device to warm up to room temperature before connecting and using it. This may take a few hours.
- Never leave the product unattended during use.
- Make sure not to squeeze, bend or in any way damage the cable.
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- the battery pack used in the low pressure: 11.6kPa
- the battery pack used ambient temperature as specified by the manufacturer: 0-35°C.
- the battery pack storage ambient temperature as specified by the manufacturer: -20~60°C.
- the battery pack transport ambient temperature as specified by the manufacturer: -20~60°C.

Walmart Inc., Bentonville, AR72716
Hotline: 1-888-516-2630

MADE IN CHINA

Date_Revision
April 8, 2025_V1.0